

Bearing No. R-BRF0304

ORDER	0.2
D1	R-BRF0304
D	6
L	3
C	4
T	0.3
R	1.5
D2	9