



LM Guide JR | JR45R1SS+1000L (B-PT1/8)

Bearing No. JR45R1SS+1000L (B-PT1/8)

MN	No connection
----	---------------