



Bearing No. FOZ1002

ORDER	0.1
L	FOZ1002
D1	1
D	2
C	0.8
T	0.1
R	0.5
F	2.6